



# MP400 | MP500

## Adding/Removing Files

### Adding Video files to MP400 using a USB:

1. The USB must contain only video files you want to play on the MP400 or MP500.
2. Delete all files from USB except the video files you want to copy to the MP400 or MP500.
3. Copy any additional video files to the USB. Remember, no spaces or odd characters in the file names.
4. The MP400 / MP500 should be turned on and booted up.
5. Next plug the USB into the USB connector on the MP400 / MP500.
6. When activated a message will come up on a grey screen saying **USB Copy in Progress Do Not Remove Until Video Starts Playing.**
7. After the copying process is completed remove the USB drive.

### Removing Old Video Files and Adding Video files to MP400 using a USB:

8. The USB must contain only video files you want to play on the MP400 or MP500.
9. Delete all files from USB except the video files you want to copy to the MP400 or MP500.
10. Using any text editor (this example will use Notepad) create a text file called USB.conf.
11. Double click on the notepad icon.
12. Type DeleteAllMedia into the workspace.
13. Click File then select Save As.
14. Verify the center Save as type: says Text Documents(\*.txt)
15. Type **USB.CONF** into the File Name field
16. Click the Save button.
17. Copy this file to the USB.
18. Copy your selected video files to the USB drive. Remember, no spaces or odd characters in the file names.
19. Unplug the USB from your computer and plug it into a MP400 or MP500.
20. When activated a message will come up on a grey screen saying **USB Copy in Progress Do Not Remove Until Video Starts Playing.**
21. After the copying process is completed remove the USB drive.